IMPORTANT SAFETY INSTRUCTIONS

WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE TAKEN, INCLUDING THE FOLLOWING:

READ ALL INSTRUCTIONS BEFORE USING APPLIANCE. KEEP AWAY FROM WATER.

DANGER — TO REDUCE THE RISK OF ELECTRIC SHOCK: ALWAYS TURN OFF BEFORE CLEANING OR STORING.

WARNING — TO REDUCE THE RISK OF BURNS, ELECTROCUTION, FIRE, OR INJURY TO PERSONS:

- 1. Read all instructions before using the appliance.
- 2. To protect against electrical hazards, do not use while bathing or in the shower.
- Close supervision is necessary when any appliance is used by or near children or invalids.
- 4. Do not operate this appliance if the appliance malfunctions or has been dropped or damaged in any manner. Return appliance to nearest service facility for examination, electrical or mechanical adjustment, or repair. No repairs should be attempted by the consumer.
- 5. Use appliance only for intended use as described in this instruction book. The

- use of attachments not recommended or sold by Conair may cause hazards.
- Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered.
- 7. Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause fire.
- 8. Do not use on a soft surface such as a bed, where openings may be blocked.
- 9. Turn switch to O (OFF) position before storage.
- 10. Do not place or store appliance where it can fall or be pulled into a tub or sink.
- 11. Do not place in or drop into water or other liquids.
- 12. If the appliance falls into water, do not reach into the water.

FOR HOUSEHOLD USE ONLY

SAVE THESE INSTRUCTIONS




OPERATING INSTRUCTIONS

- 1. Your LED lighted makeup mirror has a head with 1x/5x magnification.
- 2. This unit operates on 3 AA batteries (not included, see illustration).
- 3. After use, always turn switch to the O (OFF) position, on base of the unit.
- 4. The beauty and design of this mirror will complement any environment. Therefore, you may wish to leave the mirror displayed. However, if you choose to store the mirror, see STORAGE for detailed information.

SPECIAL FEATURE

This lighted makeup mirror uses Lifetime Energy Saving LED bulbs. Replacement bulbs are not required.



3 AA batteries needed

TO INSTALL BATTERIES (not included)

- 1. Loosen screw and remove battery cover.
- 2. Install 3 AA new batteries as indicated on battery compartment.
- 3. Replace battery cover by snapping it into place and tightening the screw.

STORAGE

Turn switch to O (OFF) position. BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MIRROR WHEN LEFT UNATTENDED. Allow to cool to room temperature before storing. Place in cool, dry area out of reach of children, where mirror will not be damaged.

MAINTENANCE

Your lighted mirror is designed for household use and is virtually maintenance free. No lubrication is needed.

If cleaning becomes necessary, turn the appliance off, allow to cool and wipe exterior with a damp cloth. Clean mirror surfaces with a glass cleaner. Do not light until you are certain mirror is completely dry. If any abnormal condition occurs, turn off the lighted mirror, and contact Conair Customer Service 1800 650 263.

INSTRUCTIONS FOR USING BATTERIES

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace old batteries of a set at the same time.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel cadmium) batteries.
- Clean the battery compartment by blowing away any debris prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment that will not be used for an extended period of time.
- When batteries begin to fail, remove promptly.

BATTERY DISPOSAL

Batteries contain various materials that must be recycled and disposed of properly. Do not dispose of in the municipal waste system.

LIMITED ONE YEAR WARRANTY

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In New Zealand our goods come with a guarantee that cannot be excluded under the Consumer Guarantee Act 1993.

Conair Australia Pty Ltd. will repair or replace (at our option) your appliance free of charge for twelve months from the date of purchase if the appliance is defective in workmanship or materials.

This warranty is an additional benefit and does not affect your legal rights. To obtain service under this warranty, please read the Warranty Leaflet included or contact Conair Customer Service at HYPERLINK "mailto:aus_info@conair.com" aus_info@conair.com.

To make a warranty claim you must retain your proof of purchase.

©2016 Conair Australia Pty. Ltd. Suite 101, 18 Rodborough Rd Frenchs Forest NSW,2086 Customer Service Hotline Australia: 1800 650 263 New Zealand: 0800 266 247 E-mail: aus_info@conair.com www.conairaustralia.com.au

ADORN Illuminated Mirror



Use and Care Guide
For your safety and continued
enjoyment of this product, always
read the instruction book carefully
before using.



Model CBE4STA