# IMPORTANT SAFETY INSTRUCTIONS

When using battery-operated appliances, especially when children are present, basic safety precautions should always be taken, including the following:

# READ ALL INSTRUCTIONS BEFORE USING THE MANICURE SYSTEM

- Close supervision is required when this product is used on, by or near children or people with certain disabilities.
- Use product only for its intended use as described in this instruction booklet.Do not use attachments not recommended by the manufacturer.
- 3. Keep the unit away from heated surfaces.
- 4. Never use while sleeping.
- Do not use outdoors or where oxygen is being administered or where aerosol (spray) products are being used.
- 6. Never operate if the product is damaged.
- 7. This product is not applicable to children

The True Glow- Manicure System handle has no serviceable parts. To buy additional manicure attachment, please call Conair Customer Service on 1800 650 263 (in Australia) or 0800 266 247 (in New Zealand).

## SENSITIVITY AND CAUTIONS SPECIAL CAUTIONS FOR DELICATE AREAS

The True Glow- Manicure System is a nail-polishing device that is intended to help you achieve smooth, shiny nails. The True Glow-Manicure System is not a medical device and is not intended to be used to treat any medical conditions.


We recommend not sharing the manicure system heads; each user should have their own

If you experience any pain or discomfort during use, stop using and consult your physician.

Do not apply pressure to nails when using manicure system; let the vibration perform the polishing. When finished, rinse hands with water and dry with a clean towel.

## TRUE GLOW™ MANICURE SYSTEM FEATURES





#### FILE ATTACHMENT

File your nails to the desired shape

#### **BUFFER ATTACHMENT**

Smooths and softens the nails surface

#### **POLISH & SHINE ATTACHMENT**

Polishes nail surface for beautiful results



# OPERATING INSTRUCTIONS

NOTE: The True Glow Manicure System operates on 1 AA battery (not included).

- 1. Remove the battery cover from the unit.
- 2. Install 1 AA battery (not included) as per the markings in the battery compartment.
- 3. Slide the battery cover back onto the unit until the battery door is firmly closed.
- Select the desired attachment and push it down onto the mounting post until firmly in place.

#### STARTING THE MANICURE SYSTEM

Slide the HIGH/LOW/OFF (II/I/O) button up one time to turn on the unit.

#### STOPPING THE MANICURE SYSTEM

Slide the HIGH/LOW/OFF (II/I/O) button to "O" to turn off the unit.

#### TWO SPEED OPTIONS

The two speeds available on your True Glow-Manicure System allows you to customize your nail care routine to suit your individual needs.

### **BATTERY WARNING**

- Always purchase the correct size and grade of battery most suitable for the intended use.
- 2. Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- 4. Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment which is not to be used for an extended period of time.
- 6. Remove used batteries promptly.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

### INSTRUCTIONS FOR USING THE MANICURE SYSTEM

- 1. Select attachment and attach to power handle.
- 2. Slide the switch to desired setting.
- Do not press the manicure system hard against your nail, as it will reduce the motion and effectiveness. Keep the manicure system in light contact and flush against the nail.
- Move the manicure system in a slow, backand-forth motion around the nailbed. Let the rotation do the polishing.
- 5. When finished, rinse your hands with water and dry with a towel.

# USER MAINTENANCE INSTRUCTIONS

### CARING FOR YOUR TRUE GLOW™ MANICURE SYSTEM

- After each use, clean the manicure system handle with a damp cloth to remove any residue.
- Clean unit thoroughly each week to help remove residue, wipe with a dry cloth and store unit in its box or in a clean, dry place.
- Remove manicure system heads once a week and rinse under warm, soapy water to remove residue accumulated during treatment. Allow manicure system heads to air-dry. Store in a clean, dry place.
- 4. Do not use abrasive cleaners for cleaning.
- 5. Do not put unit in dishwasher for cleaning.
- When storing the manicure system off the unit, use the protective cover.

Note: It is recommended to replace the manicure system attachments every 60 days, as they wear over time will be less efficient.

To buy additional manicure attachments, please call Conair Customer Service on 1800 650 263 (in Australia) or 0800 266 247 (in New Zealand).

## TROUBLE-SHOOTING GUIDE

| THE MANICURE<br>SYSTEM IS NOT<br>WORKING.                           | Make sure the battery contacts on the unit and base are clean. See User Maintenance Instructions for cleaning procedure.      Make sure the batteries are installed properly |
|---|--|
| THE MANICURE<br>SYSTEM OPERATES<br>AT A SLOW SPEED.                 | Replace the batteries.   |
| THE MANICURE<br>SYSTEM HEAD<br>VIBRATES OR FALLS<br>OFF DURING USE. | Make sure the manicure system head is snapped on properly.     Replace the manicure system head.   |

Due to continued product enhancements, product image may differ slightly from actual product

purchased

# LIMITED ONE YEAR WARRANTY

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In New Zealand our goods come with a guarantee that cannot be excluded under the Consumer Guarantee Act 1993.

Conair Australia Pty Ltd. will repair or replace (at our option) your appliance free of charge for twelve months from the date of purchase if the appliance is defective in workmanship or materials.

This warranty is an additional benefit and does not affect your legal rights. To obtain service under this warranty, contact Conair Customer Service at aus info@conair.com.

To make a warranty claim you must retain your proof of purchase.

#### 

©2017 Conair Australia Pty Ltd.
Suite 101, 18 Rodborough Rd
Frenchs Forest NSW, 2086
Australia
Customer Service Hotline Australia: 1800 650 263
New Zealand: 0800 266 247
E-mail us at: aus\_info@conair.com
www.conairaustralia.com.au

...

# renew · refresh · revive

Manicure System for salon results





MAN1A