

# IMPORTANT SAFETY INSTRUCTIONS

WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE TAKEN, INCLUDING THE FOLLOWING:

**READ ALL INSTRUCTIONS BEFORE USING APPLIANCE. KEEP AWAY FROM WATER.**

## DANGER

When the unit is used in a bathroom, remove batteries before use since the proximity of water presents a hazard even when the unit is switched off.

## WARNING — TO REDUCE THE RISK OF BURNS, ELECTROCUTION, FIRE, OR INJURY TO PERSONS:

1. Read all instructions before using the appliance.
2. To protect against electrical hazards, do not use while bathing or in the shower.
3. This appliance should not be used by adults or children whose lack of experience, product knowledge or disability might cause a hazard, unless they have been correctly instructed and are adequately supervised.  
Children should always be supervised to ensure that they do not play with this product.
4. Do not operate this appliance if the appliance malfunctions or has been dropped or damaged in any manner. Return appliance to nearest service facility for examination, electrical or mechanical adjustment, or repair. No repairs should be attempted by the consumer.
5. Use appliance only for intended use as described

- in this instruction book. The use of attachments not recommended or sold by Conair may cause hazards.
6. Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered.
  7. Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause fire.
  8. Do not use on a soft surface such as a bed, where openings may be blocked.
  9. Turn switch to Off position before storage.
  10. Do not place or store appliance where it can fall or be pulled into a tub or sink.
  11. Do not place in or drop into water or other liquids.
  12. If an appliance falls into water.  
**Do not reach into the water.**

## INSTRUCTIONS FOR USING BATTERIES

- Always purchase the correct size and grade of battery most suitable for the intended use.
  - Replace old batteries of a set at the same time.
  - Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel cadmium) batteries.
  - Clean the battery compartment by blowing away any debris and also those of the device prior to battery installation.
  - Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment which is


- not to be used for an extended period of time.
- Remove batteries promptly.

## FOR HOUSEHOLD USE ONLY

# SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

**CAUTION: BE SURE DIRECT SUNLIGHT DOES NOT STRIKE THE MIRROR; REFLECTED SUNLIGHT CAN CAUSE FIRE.**

1. Your LED lighted makeup mirror has a 21.5 x 16.5cm oval design head with a 7x/1x magnification.
2. This unit operates on 3 AA batteries (not included, see illustration).
3. After use, always turn switch to the Off position.
4. The beauty and design of this mirror will complement any environment. Therefore, you may wish to leave the mirror displayed. However, if you choose to store the mirror, see STORAGE for detailed information.
5. This mirror has an High/Off/Low settings switch on the base.



3 AA batteries needed

(Fig. 1)

## TO INSTALL BATTERIES (not included)

1. Remove battery cover.
2. Install 3 AA new batteries as indicated on battery compartment (Fig. 1).
3. Replace battery cover by snapping it into place.

## Special Feature

This lighted makeup mirror uses Lifetime Energy Saving LED bulbs. Replacement bulbs are not required.

## STORAGE

Turn switch to off position. BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MIRROR WHEN LEFT UNATTENDED. Allow to cool to room temperature before storing. Place in cool, dry area out of reach of children, where mirror will not be damaged.

## MAINTENANCE

Your lighted mirror is designed for household use and is virtually maintenance-free. No lubrication is needed.

If cleaning becomes necessary, turn off the appliance, allow to cool and wipe exterior with a damp cloth. Clean mirror surfaces with a glass cleaner. Do not light until you are certain mirror is completely dry. If any abnormal condition occurs, turn off the lighted mirror, allow it to cool, and return it to an authorized service center for repair.

## LIMITED ONE YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.


This warranty is an additional benefit and does not affect your legal rights. To obtain service under this warranty, please fill in and return the warranty registration as instructed. A receipt of purchase is required to make a warranty claim. Please attach a copy of your purchase to this document or your warranty form.

©2011 Conair Australia Pty Ltd  
Suites 20 and 21,  
7 Narabang Way, Belrose NSW 2085  
Customer Service Hotline (Australia):  
1800 650 263

Customer Service e-mail:  
aus\_info@conair.com  
Conair New Zealand Ltd.,  
PO Box 251159, Pakuranga, Auckland, 1706, New Zealand  
Customer Service Hotline (New Zealand): 0800 266 247  
Model CBE51LEDA

# reflections

LED LIGHTED MIRROR



body benefits<sup>®</sup>  
by CONAIR

Battery operated (3 AA not included)

For your safety and continued enjoyment of this product,  
always read the instruction book carefully before using.  
Model CBE51LEDA

IB-10441