

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety instructions should always be followed, including the following: Polythene bags over product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children.

DANGER – When the facial sauna is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the unit is switched off.

WARNING – Do not use the facial sauna or manicure & pedicure set in or near bathtubs, showers or other vessels containing water.

- Do not immerse the facial sauna or manicure & pedicure set in water or other liquids.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Take care to avoid contact between the hot surfaces of the appliances and the skin, paying particular attention to the face, neck and hands
- The facial sauna and manicure & pedicure set is not intended for use by persons (including children) with reduced physical, sensory or medical capabilities, or lack of experience or knowledge, unless they are supervised and have been given instruction concerning the use of the appliances by persons responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.




- IMPORTANT** – Always unplug the appliances when not in use or before cleaning.
- Do not leave unattended when plugged in or switched on. Do not place on any heat sensitive surface and always allow to cool before storing away.
 - Do not use any attachments other than those supplied by Conair Australia Pty Ltd.
 - Use the appliances only for their intended use as described within this instruction booklet.
 - These appliances are not intended for commercial use.
 - Never drop or insert any object into an opening of the appliances.
 - Ensure the facial sauna is switched off before plugging into a suitable power outlet.
 - Only use the facial sauna on a hard, flat surface.
 - Always unplug the facial sauna when not in use and when filling, emptying, cleaning

or moving the appliance.

- Take care when emptying the facial sauna as hot water may still remain in the reservoir. Ensure the appliance has cooled down and is switched off before emptying or moving the appliance.
- Ensure your hands are dry before touching the control switch or plug of the facial sauna.
- Do not add boiling or steaming water into the facial sauna. Use cool or warm water only.
- Take care not to spill any water onto the control switch of the facial sauna. Only use the water cylinder when pouring water into the reservoir.
- Never use the facial sauna without water in the reservoir.
- Never use additives such as salt, perfume or dye, use clean water only.
- Never use the facial sauna without the comfort shaped mask.
- Never place your face too close to the facial sauna in one position, as this could cause scalding.
- Do not touch the steam that comes out of the base of the reservoir.
- Never touch the base of the reservoir, or the water in the reservoir when the appliance is switched on.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not operate the facial sauna and manicure & pedicure set under a blanket or pillow. Excessive heating can occur and cause fire, electric shock or injury.
- Keep the facial sauna power cord away from heated surfaces.
- Do not use an extension cord with the facial sauna.
- Do not carry the facial sauna by the supply cord or use cord as a handle.
- Do not use this facial sauna if the supply cord is damaged. In the event of damage, discontinue use and contact your dealer for instructions on returning it for examination or exchange.
- After use do not wrap the cord around the facial sauna, as in time this may cause the cord to fracture. Coil cord loosely beside the facial sauna.
- Always ensure that the voltage to be used corresponds to the voltage marked on the facial sauna.
- For additional protection, the installation of a residual current device (RCD) with a rated operating current not exceeding 30mA is advisable in the electrical current circuit supplying the bathroom. Ask your installer for advice.

FACIAL SAUNA

Beautiful skin needs more than just a daily cleaning regime. It needs the deep cleansing benefits of a facial sauna. Gentle, deep cleansing warm steam mist opens pores, draws out impurities and lets your skin breathe.



CAUTION:

- This appliance should not be used if any of the following cases exist, unless directed by a physician – inflammation of the skin, open and fresh wounds, broken skin or infections.
- If you are pregnant, please consult your physician before using.
- Consult your physician or dermatologist for instructions on how to best use the facial sauna for your specific skin type.
- Do not allow children to use this appliance.

Tips for Preparing your Face for Steaming

Before beginning, cleanse your face, neck and throat following your daily cleansing regime. Apply moisturizer to the face, neck and throat and ensure the area is well moisturized.

The eye area:

Give special care to the eye area prior to using the facial sauna. Lightly massage additional moisturizer or eye cream on the eyelids and under the eyes prior to using the facial sauna.

How to use your Facial Sauna

1. A plastic cover has been placed over the plug to protect it during transportation. Remove the plastic cover from the plug before use.
2. Ensure the appliance is in the 'O' off position and unplugged from the power outlet when preparing the facial sauna for use.
3. Place the facial sauna on a hard, dry and level flat surface, such as a table or benchtop.
4. Remove the comfort shaped mask from the base of the facial sauna by holding the base with one hand and the mask with the other. Then, twist the mask to the left until you hear it click, then lift the mask up and away from the base of the facial sauna. Place mask aside.
5. Using the water cylinder, fill the water reservoir with cool or warm tap water to the 'MAX' fill line, as indicated in the bottom of the water reservoir. (Fig.1)



Fig.1

6. Place the mask back onto the base of the facial sauna by aligning the two plastic lugs on the outside of the mask with the two holes inside the base. Push the mask down and twist to the right until it clicks back into place. (Fig.2)



Fig.2

7. Plug the appliance into a suitable power outlet and switch the appliance on to the 'I' position. The red light will illuminate to indicate that the facial sauna is heating up.
8. Allow approximately 3-4 minutes for the warm steam mist to develop, and then place your face gently against the rim of the comfort shaped mask. Close your eyes and relax as the soothing mist begins its' deep cleansing action. For full benefits of the steam mist on your neck and throat, tilt your head backward so your throat is approximately 2cm from the comfort shaped mask. Mist your throat for 2 minutes and then gently turn your neck slowly from side to side to feel the full benefits of the warm, deep cleansing steam mist.
9. Never pick up the appliance while it is switched on, or while water remains in the reservoir.

NB – One fill of water provides approx 15 minutes of warm steam mist. If the facial sauna should run out of water, switch the appliance off immediately, then re-fill with water and continue your facial.

10. If more steam is desired, place a towel over your head so that it covers the mask and side of the facial sauna.
11. Remove your face occasionally and blot with a cool, damp towel. Immediately after steaming, rinse your face with cool water.

Recommended Steaming Times

Generally, the facial sauna should be used for a minimum of 5 minutes, but no longer than 30 minutes. Treatment may be applied once or twice daily as desired. You should adjust your steaming time to suit your needs and personal comfort. If you have any concerns regarding treatment, we recommend consulting your physician or dermatologist.


User Maintenance

After each use, the facial sauna should be cleaned to ensure optimum performance.

1. Ensure the facial sauna is switched off, unplugged from the power outlet and has cooled before emptying the water reservoir (if any water remains) or before cleaning. Empty water from the bottom of the facial sauna (opposite side to the on/off switch) into a sink. NEVER SUBMERGE THE FACIAL SAUNA IN WATER.
2. After each use, using a clean, dry cloth wipe the water reservoir and comfort shaped mask dry. THE WATER RESERVOIR SHOULD BE CLEANED AFTER EACH USE, TO AVOID THE ACCUMULATION OF OILING RESIDUES.
3. Wipe the base of the facial sauna with a clean, damp cloth and then polish lightly with a dry one.
4. To store the appliance, coil the cord loosely beside the facial sauna. Do not warp the cord around the facial sauna as this cord damage the power cord. Never hang the facial sauna by the power cord. Store away in a box or clean, dry place.

MANICURE & PEDICURE SET

Use the 8 piece manicure and pedicure set for a professional, salon finish.



Instructions for using Batteries

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace old batteries of a set at the same time.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel cadmium) batteries.
- Clean the battery compartment by blowing away any debris and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment which is not to be used for an extended period of time.
- Remove batteries promptly.

How to use your Manicure and Pedicure Set

1. Locate the battery compartment cover on the top of the power handle.
2. Remove the cover and place aside.
3. Insert 2x AAA alkaline batteries as indicated by the markings inside the compartment.
4. Ensure the batteries are fixed in place, then replace the cover by sliding over the battery compartment.
5. This manicure and pedicure set has 2 settings for easy control - low and high. Use the low setting when using the shaping cones and the high setting when using the buffing discs.
6. The rotary head and the power handle are independent to each other.
7. To attach the discs to the rotary head, insert the metal post into the white plastic tube opening on the head of the power handle, then gently push down. To remove the attachments, simply pull off.

For best results

1. Soak your nails in warm soapy water, then dry thoroughly.
2. Using the cuticle pusher, gently push cuticles back. If desired, massage lotion or cream into the cuticles to help soften them and promote healthy nails.
3. Install the desired attachment:
 - a. use the **shaping cones** to shape nails and eliminate ragged edges
 - b. use the **abrasive buffing discs** to buff hard nails
 - c. use the **buffing discs** to buff soft nails
 - d. use the **felt buffing disc** to gently and carefully polish the ridges and furrows that may be present on the nail's surface, using short intermittent strokes. This is not recommended more than once every eight weeks.
4. Slide switch to 'On' position to start manicure/pedicure.
5. Finish your manicure/pedicure by applying moisturizing lotion or cream.

User Maintenance

The manicure and pedicure set is designed for household use and is virtually maintenance free. No lubrication is needed. If cleaning is necessary, wipe with a clean damp cloth.

Limited One Year Warranty

Conair Australia Pty Ltd. will repair or replace (at our option) your appliance free of charge for twelve months from the date of purchase if the appliance is defective in workmanship or materials. This warranty is an additional benefit and does not affect your legal rights. To obtain service under this warranty, please fill in and return the Warranty Registration as instructed.

CONAIR®

©2010 Conair Australia Pty Ltd, Suites 20 & 21,
7 Narabang Way, Belrose NSW 2085 Australia
Customer Service Hotline (Australia): 1800 650 263

Customer Service e-mail: aus_info@conair.com

Conair New Zealand Limited, PO Box 251159,
Pakuranga, Auckland 1706 New Zealand
Customer Service Hotline (New Zealand): 0800 266 247

Body Benefits is a registered trademark of Conair Corporation

Model CGP2RA

PAMPER PACK



Use and Care Guide

For your safety and continued enjoyment of this product, always read the instruction booklet carefully before using

body benefits
by CONAIR

IB-

Model CGP2RA