

# IMPORTANT SAFETY INSTRUCTIONS

WHEN USING AN ELECTRIC FURNISHING, ESPECIALLY WHEN CHILDREN ARE PRESENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE TAKEN, INCLUDING THE FOLLOWING:

**READ ALL INSTRUCTIONS BEFORE USING APPLIANCE.**  
**KEEP AWAY FROM WATER.**

## DANGER

TO REDUCE THE RISK OF ELECTRIC SHOCK: ALWAYS UNPLUG THIS APPLIANCE FROM THE ELECTRICAL OUTLET BEFORE CLEANING.

**WARNING** — TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:

1. UNPLUG FROM OUTLET BEFORE PUTTING ON OR TAKING OFF PARTS.
2. Close supervision is necessary when this furnishing is used by or near children, invalids, or disabled persons.
3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
4. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
5. Keep the cord away from heated surfaces.
6. Never drop or insert any object into any opening.

7. Do not use outdoors.
8. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
9. Never operate the furnishing with the air openings blocked, keep the air openings free of lint, hair, and the like.
10. To disconnect, turn all controls to the OFF or 0 position, then remove plug from outlet.
11. Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause fire.
12. Do not use on a soft surface such as a bed, where openings may be blocked.
13. Do not place or store this furnishing where it can fall or be pulled into a tub or sink.
14. If this furnishing falls into water, unplug it immediately. Do not reach into the water.
15. Never use while sleeping.
16. To protect against electrical hazards, do not use while bathing or in the shower.
17. Unplug the furnishing from outlet before cleaning. Do not leave mirror unattended when it is plugged in.
18. Use in any 240 volt electrical outlet (ordinary house current). Do not use in any other electrical outlet.
19. This appliance is not toy, keep away from children.
20. The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.

**FOR HOUSEHOLD USE ONLY**

**SAVE THESE INSTRUCTIONS**

# INSTALLATION INSTRUCTIONS

## Wall Mount Mirror

1. Remove mounting bracket from base of mirror. Leave long screws in bracket.
2. Using 9.5mm (3/8-inch) drill size, drill two holes in wall the same distance apart as two opposite slots in bracket. Screw into wall stud if possible. If drilling into stud, use 3mm (1/8-inch) drill size. Otherwise, insert two wall anchors in holes.

**CAUTION: Do not drill into electrical wiring through wall. Check with electrician if necessary.**

3. Screw bracket onto wall, into the anchors.
4. Attach mirror to bracket by placing long screws through the two holes in mirror's base. Secure with knurled nuts. Cord should be extending toward floor.

# OPERATING INSTRUCTIONS

1. Your lighted makeup mirror will adjust to many different angles. Simply tilt the head backward or forward to adjust to the desired angle. Your mirror will also swivel so that you can use either the normal view or the magnifying view located on the opposite side but the mirror frame can't be 360 degrees rotated.
2. Plug into any standard wall outlet (240 volt AC). Switch the mirror to I setting to switch on.
3. After use, switch the mirror to the 0 setting to turn off.

## Special Feature

This lighted makeup mirror uses Lifetime Energy Saving LED bulbs. Replacement bulbs are not required.

## STORAGE

Turn switch to OFF position. BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MIRROR WHEN LEFT UNATTENDED. Allow to cool to room temperature before storing. Place in a cool, dry area, out of reach of children, where mirror will not be damaged.

## MAINTENANCE

Your lighted mirror is designed for household use and is virtually maintenance free. No lubrication is needed.

If cleaning becomes necessary, turn the appliance off, disconnect the appliance from the power source, allow to cool and wipe exterior with a cloth. Clean mirror surfaces with a glass cleaner. Do not light until you are certain mirror is completely dry, to protect against electrical hazards.

If any abnormal condition occurs, unplug the lighted mirror, allow it to cool, and return it to an authorised service center for repair.

Handle cord carefully to prolong its life; do not jerk or strain at plug connections, or wrap cord around mirror for storage. This could cause damage to the cord and the mirror could short circuit. To store mirror, coil cord loosely.

**WARNING:  
IF YOU THINK  
THE POWER IS  
OFF WHEN THE  
SWITCH IS OFF,  
YOU'RE WRONG.**

**KEEP AWAY FROM WATER**



Everybody knows that electricity and water are a dangerous combination. But did you know that an electrical appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

**ALWAYS UNPLUG  
SMALL APPLIANCES**

## LIMITED ONE YEAR WARRANTY

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In New Zealand our goods come with a guarantee that cannot be excluded under the Consumer Guarantee Act 1993.

Conair Australia Pty Ltd. will repair or replace (at our option) your appliance free of charge for twelve months from the date of purchase if the appliance is defective in workmanship or materials.

This warranty is an additional benefit and does not affect your legal rights. To obtain service under this warranty, please read the Warranty Leaflet included or contact Conair Customer Service at [aus\\_info@conair.com](mailto:aus_info@conair.com). To make a warranty claim you must retain your proof of purchase.

**CONAIR®**

©2018 Conair Australia Pty. Ltd.  
Suite 101, 18 Rodborough Rd  
Frenchs Forest NSW, 2086  
Customer Service Hotline  
Australia: 1800 650 263  
New Zealand: 0800 266 247  
E-mail: [aus\\_info@conair.com](mailto:aus_info@conair.com)  
[www.conairaustralia.com.au](http://www.conairaustralia.com.au)

**Aura**  
LED WALL-MOUNTED MIRROR



**body benefits®**  
by CONAIR®

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

Model CBE6BLEDA

IB-