

indoor/outdoor
massaging slippers
with flexible soles



INSTRUCTION BOOKLET

For your safety and continued enjoyment of this product, always read through the instruction book carefully before using.

CVSM20BA

by **CONAIR**[®]

body benefits[®]

WARRANTY

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

In New Zealand our goods come with a guarantee that cannot be excluded under the Consumer Guarantee Act 1993.

LIMITED ONE YEAR WARRANTY

This product is subject to the express warranty given on the warranty card included with the product, as may be amended by reference to and in accordance with the terms of the warranty cards displayed on Conair website www.conairaustralia.com.au.

To make a warranty claim you must retain your proof of purchase. Further details can be found at www.conairaustralia.com.au and click on 'customer service'.

Your Body Benefits by Conair Massaging Slippers provide a soothing massage at the touch of a button. 2 AAA batteries are required for the massaging feature, 1 for each slipper (not included).

To insert the batteries, first locate the battery compartment in each slipper by pulling up on the tab located at the heel of the slipper. Underneath, remove the battery cover by using a Phillips head screwdriver to remove the screws. You will see a place for 1 AAA battery.

Insert the batteries so that the +/- terminals of the batteries match the +/- markings in the battery compartment.

WARNING: Use only alkaline batteries. DO NOT mix old and new batteries. DO NOT mix alkaline, standard (carbon-zinc), or rechargeable (nickel cadmium) batteries.

Clean the battery contacts and also those of the product prior to battery installation. Remove used batteries promptly.

Close the battery compartment.

Place the slippers on your feet and locate the On/Off button on the side of the slipper. Press once to turn on the massaging motor. After your foot massage, turn the massager off by pushing the On/Off button again.

RECOMMENDED MASSAGING TIMES

Generally, massage should last only 15 minutes on any one particular part of the body. Treatment may be applied once or twice daily as desired.

As metabolism varies among individuals, so does their response to massage. You will soon adjust the time to suit your particular needs and personal comfort. If you have any doubts regarding treatment, we recommend you consult your physician.

STORAGE

If you are travelling or are not going to use the massaging feature for more than a few days, remove the batteries.

Store the slippers in a safe, dry location out of direct sunlight and out of reach of children.

CVSM20BA

©2015
Conair Australia Pty. Ltd.
Suite 101, 18 Rodborough Rd
Frenchs Forest NSW, 2086
Australia
Customer Service Hotline Australia: 1800 650 263
New Zealand: 0800 266 247
E-mail us at: aus_info@conair.com
www.conairaustralia.com.au

IB-15/2-17

IMPORTANT SAFETY INSTRUCTIONS

Please read through these instructions carefully and retain for future reference. This appliance is intended for household use.

WARNING:

- When using electrical appliances, especially when children are present, basic safety instructions should always be followed.
- Polythene bags over product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children.

DANGER:

- Do not use this appliance in or near bathtubs, showers, basins or other vessels containing water.
- Do not immerse the appliance in water or other liquids.
- Do not reach for an appliance that has fallen into water.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure they do not play with the appliance.



IMPORTANT:

- Always remove the batteries when not in use or before cleaning. Do not leave unattended when switched on. Do not place on any heat sensitive surface.
- Use this appliance only for its intended use and as described in this instruction booklet.
- Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock or injury to persons.
- Do not use any other attachments other than those supplied with this product.
- Never drop the appliance or insert any object into an opening, except feet.
- Never fall asleep or use while sleeping.
- Do not use while bathing or in the shower.

- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- Slippers are intended primarily for indoor use. They may be worn outdoors in dry weather for limited periods of time.
- Spot clean only.
- Keep your feet dry when using.

CAUTION:

- This massager should not be used in the following cases: Tuberculosis, benign and malignant tumors, hemorrhages, inflammations of the skin, phlebitis and thrombosis, open and fresh wounds, bruises, broken skin or varicose veins, undetermined calf pain, or joint pain.
- If you experience pain in a muscle or joint for a prolonged period of time, discontinue use and consult your doctor. Persistent pain could be a symptom of a more serious condition.
- Do not use on any unexplained pain, or swollen muscles, or following a serious muscular injury, before consulting your physician.

MASSAGING SLIPPERS



Soothing massage at the touch of a button
(2 AAA batteries required for massaging feature, 1 for each slipper, not included)

Durable soles with grip treads for indoor/outdoor use